

# RS800 Transaxle

## Axle shaft seal replacement


This operation does not require to remove the transaxle from the tractor, but only to remove the rear wheel of the tractor.

### I- Remove rust from the axle shaft

Remove the rust and clean the axle shaft before removing the damaged seal.



**Before**



**After**

### II- Remove the damaged seal using a small flat screwdriver



Please feel free to contact us for more information  
[service@generaltransmissions.com](mailto:service@generaltransmissions.com)

# RS800 Transaxle

## Axle shaft seal replacement

### III- Lubricate the axle shaft, seal and bushing



**Damaged  
seal**



**New seal**



### IV- Install the new seal and clean the shaft.



Please feel free to contact us for more information  
[service@generaltransmissions.com](mailto:service@generaltransmissions.com)



# RS800 Transaxle

## Add grease into the unit

### INFORMATION:

- As the RS800 transaxle is a mechanical transmission, the grease is in there only for heat dispersion and gear lubricating.
- The grease quantity is therefore much less critical than oil level in a hydrostatic transaxle and, even if the leak seems excessive, there is usually no need to add any grease while replacing the seals.
- Nevertheless, if you feel it is necessary, we recommend not to add more than 1lb of grease EP00, GT42737 (available on Amazon.com).
- As the RS800 transaxle is not serviceable, there is no easy way to add lubricant. If adding grease please see the instructions below.


### I- Remove Driven kit and protection cover

-Remove the 3 screws to liberate the cover, press the aluminum ramp to compress the spring and liberate the pin, then remove the aluminum ramp, spring and mobile flange

Screwing torque:

$2.2 \pm 0.1$  Nm

$(1.6 \pm 0.1$  lb-ft)



# RS800 Transaxle


## Add grease into the unit

-Unscrew the nut using the special tool P/N 79252 (see p.19), then remove the fixed flange.

Screwing torque: 53,5  $\pm$ 2 lb-ft



Make sure not to lose the 8 balls under the flange




When re-installing the components:

- Make sure the 8 balls are present under the flange.
- Respect the torques of the nut and screws.
- Make sure the belt is properly positioned in the pulley.
- Ensure that the spring is between the mobile flange and the aluminum ramp.



Screwing torque: 3.2 $\pm$ 0.1 Nm  
(2.4 $\pm$ 0.1 lb-ft)




# RS800 Transaxle

## Add grease into the unit

### II- Remove Brake lever and Bypass lever



-Disconnect the brake spring, then remove the screws, to liberate the aluminum lever.



Screwing torque:  $3.2 \pm 0.2$  Nm  
( $2.4 \pm 0.1$  lb-ft)



-Separate and hold the 2 strips of the lever, to release the two studs and allow the lever removal.



### III- Add grease

-EP00 grease can be injected through the opening.

